



Pos	Part Number	Description	Additional Text	Quantity
1	SPNO	Non orderable part	TB_2359795	1.00
2	J410001701402	Grooved ball bearing 6303		1.00
3	J625063040	DEEP GROOVE BALL BEARING 6304		1.00
4	90230079000	STOPPER BALANCER SHAFT BEARING		2.00
5	J01665060123S	Hex collar screw, M6x12		2.00
6	90130004004	Bearing ball		1.00
7	J440002201300	bush bimetallic		2.00
8	J618131912	NEEDLE ROLLER BEARING HK1312		1.00
9	90234030000	BUSH SHIFT RAIL		2.00
10	J760122455	SHAFT SEALING RING 12X24X5,5		1.00
11	0760122406	Shaft seal ring 12x24x6		1.00
14	90240018000	BUSH STARTER SHAFT		1.00

15	90230084000	HAUPTLAGER		2.00
16	J400002201600	bearing roller		1.00
17	J410001501300	bearing ball id15xod42xt13xc3l		1.00
18	90230022000	Pipe breather		1.00
19	J011050133	HH COLLAR SCREW M5X13 SW8		2.00
20	J618131912	NEEDLE ROLLER BEARING HK1312		1.00
21	90130003004	Seal - oil		1.00
22	J760003447000	Seal Oil		1.00
23	0738060101S	Oval head screw M6X10 precoat		1.00
24	96330066000	PLATE STOPPER		1.00
25	96330064000	NOZZLE JET OIL		1.00
26	90130164000	OIL NOZZLE		1.00
27	96311023000	SENSOR INDICATOR GEAR		1.00
28	J770002024000	O RING		1.00
29	J025050163S	FLANGED BOLT M5X16		2.00
30	96339034000	SENSOR ASSEMBLY PICK UP		1.00
31	J025060350	FLANGED BOLT M6X35 WS8		6.00
32	J900000607002	bolt flanged M6x70		6.00
33	96330047000	guard chain		1.00
34	J005060123S	SCREW PAN CROSS M6X12 PH SS		3.00
35	96303096000	Cover Rear LH		1.00
36	J900000601607	SCREW SOCKET M6X1		3.00
37	90238029003	OIL NOZZLE		1.00
38	90230066300	OIL NOZZLE		1.00
39	90130024000	PIN DOWEL 8X6,4X14MM	14mm length	1.00
40	96340020010	retainer gear starter		1.00
41	J025060141	Hex collar screw M6X14		1.00
42	90130003007	DOWEL D14		3.00
43	90130024000	PIN DOWEL 8X6,4X14MM	14mm length	2.00
44	J900000802004	Hexagonal bolt M8x20		2.00
45	J690000815000	plain washer		1.00
46	J780001515000	O-ring		1.00
47	J900000607003	bolt flanged M6x1		4.00