




Pos	Part Number	Description	Additional Text	Quantity
1	83005082070	ENDCAP SPARKY ATV 08		1.00
2	83005082050	SILENCER HOUSING SPARKY ATV		1.00
3	77005081016	STUFFING YARN EXC-F 07		1.00
4	58705078350	STUFFINGYARN 350 GRAMM '99		1.00
5	58605083010	SCREW TORX M5X10 05		12.00
6	83005082060	CONNECTING CAP CPL. ATV		1.00
7	0025060306	HH collar screw M6x30 TX30		2.00
8	0137060003	spring washer DIN 137 B - 6		2.00
9	54605069000	BUSHING 7,5X12X28X7,8 '96		4.00
10	54605068000	EXHAUST BRACKET RUBBER BLACK		3.00
11	59405069000	BUSHING FOR EXHAUST SUPPORT 03		2.00

12	0025080256	HH collar screw M8x25		1.00
13	54603048000	RANGE CHANGE METAL NUT M8		1.00
14	83005007000	EXHAUST MANIFOLD R/S CPL.		1.00
15	50305016000	TEN.SPRING L=62MM EY.MOVEABLE		3.00
16	83005082000	EXH. SIL. CPL. R/S ATV SPARKY		1.00
17	77005081055	SIL. ELEMENT EXC-F 07		1.00
18	54603048100	clip nut M6		2.00