



Pos	Part Number	Description	Additional Text	Quantity
1	6010302320030	SIDE STAND L=349MM 07		1.00
3	62503027100	SCREW F. SIDE STAND M10X31,2		1.00
4	61003028001	SCREW SIDE STAND SPRING 05		1.00
6	61003024000	SPRING L=116 MM 05		1.00
7	60003026000	SIDE STAND BRACKET 03		1.00
8	0035100309S	AH collar screw M10x30 ISA45	ONLY FOR ADVENTURE R	2.00
9	60103028000	SIDE STAND PICKUP 06		1.00
10	0035100249	AH collar screw M10x24 ISA45		2.00
11	61011045000	Side stand sensor		1.00
12	60103029000	SUPPORT F.SIDE STAND SWITCH 06		1.00
13	0084040123	CYL.HEAD SCREW DIN84A M4x12		2.00
14	0985040003	SELF LOCKING NUT DIN0985-M 4		2.00

15	60103029050	MAGNET HOLDER ADV. 06		1.00
16	0025060126	HH collar screw M6x12 TX30		1.00
22	6000302200030	CENTER STAND L=379MM 04		1.00
23	60003030000	SPRING FOR CENTER STAND 03		2.00
24	60003022115	SPRING TENSIONER 03		1.00
25	0125080003	washer DIN 125 A -8.4		1.00
26	0025080306	HH collar screw M8x30		1.00
27	56503093000	SPECIAL SCREW M10X55 WS=17		2.00
28	0125100003	washer DIN 125 A 10.5	ONLY FOR 640 DUKE	2.00
29	60003022020	BEARING BUSH CENTER STAND 03		2.00
30	60003022021	SPACER 10X16X38 MM 03		2.00