



| Pos | Part Number | Description | Additional Text | Quantity |
|-----|-------------|--------------------------------|-----------------|----------|
| 1 | 60105008000 | EXHAUST PIPE REAR 06 | | 1.00 |
| 2 | 60105007000 | EXHAUST PIPE FRONT 06 | | 1.00 |
| 3 | 61005005000 | Exhaust gasket 05 | | 2.00 |
| 4 | 61041090000 | LAMBDA SENSOR 05 | | 2.00 |
| 6 | 51010086100 | self-locking nut M8 Cu | | 4.00 |
| 7 | 0125080003 | washer DIN 125 A -8.4 | | 2.00 |
| 8 | 60005011000 | THERMAL SHIELD 05 | | 1.00 |
| 9 | 0991060082 | FLAT H.SCREW M6X8 DIN7991 NIRO | | 3.00 |
| 20 | 60005048000 | DISTRIBUTOR TUBE LC8 03 | | 1.00 |
| 21 | 60005005001 | GRAPHIT RING 42X47X25 03 | | 2.00 |
| 22 | 60105051000 | CLAMP CPL. D=49,2MM 06 | | 2.00 |
| 23 | 58405085044 | SILENCER BRACKET CPL. 2001 | | 2.00 |
| 24 | 0137060003 | spring washer DIN 137 B - 6 | | 4.00 |

| | | | | |
|----|----------------|-------------------------------|--|------|
| 25 | 0025060206 | HH collar screw M6x20 TX30 | | 4.00 |
| 26 | 54305068100 | damp. component silicone grey | | 4.00 |
| 27 | 56505069000 | Spacer bushing 8.4X12X16 | | 2.00 |
| 28 | 36003014000 | LOCK WASHER 8MM | | 2.00 |
| 29 | 0025080306 | HH collar screw M8x30 | | 2.00 |
| 30 | 60105082100 | SILENCER L/S 09 | | 1.00 |
| 31 | 54308042000 | RUBBER BUFFER | | 2.00 |
| 32 | 60005005002 | EXHAUST GASKET 03 | | 2.00 |
| 33 | 0025080166 | HH COLLAR SCREW M8X16 TX40 | | 6.00 |
| 34 | 60005095000 | CLAMP FOR SILENCER CPL. 03 | | 2.00 |
| 35 | 0025080256 | HH collar screw M8x25 | | 2.00 |
| 36 | 0021080003 | WASHER DIN9021-A 8,4 | | 2.00 |
| 38 | 6000508500001S | SILENCER/HANDLE HOLDER L/S 07 | | 1.00 |
| 39 | 6000508600001S | SILENCER/HANDLE HOLDER R/S 07 | | 1.00 |
| 40 | 0125080003 | washer DIN 125 A -8.4 | | 4.00 |
| 41 | 0025080356 | HH collar screw M8x35 TX40 | | 4.00 |
| 42 | 60105083100 | SILENCER R/S 09 | | 1.00 |