




Pos	Part Number	Description	Additional Text	Quantity
1	A60607013000	Fuel tank		1.00
2	76507065100	RUBBER BUSHING 11,7X24,7 L=26		2.00
3	76507060300	Bearing sleeve, top		2.00
4	76507061100	Bearing sleeve, bottom		1.00
5	A60607028000	tank mounting plate right cpl.		1.00
6	76107027000	Tank retaining plate, left, cm		1.00
7	0145830801600	cap head bolt ISO 14583-M8x16-		6.00
9	0025080306S	HH COLLAR SCREW M8X30 TX40		2.00
10	61707052000	Rider seat lock cpl.		1.00

11	0738060185S	oval head screw M6x18 A2-70 S		2.00
12	76907008000	Fuel tank cap		1.00
13	43205062100	silentbloc 20x15-M6x10-(1)	ONLY FOR USA	3.00
14	58605083010	SCREW TORX M5X10 05		4.00
15	76507108050	Closure flange		1.00
16	0770050030	O-ring 50.00X3.00 VITON		1.00
17	76506010100	Splash protection		1.00
18	72210079100	Supporting shell		2.00
19	0025060106	HH collar screw M6x10 TX30		2.00
20	0320001400800	Fastening clamp		1.00
21	76507066000	RUBB.BEAR.BOX 12x24x35 L=24,5		2.00
22	61711094100	Cable strap w.plugin foot for		2.00
23	0738050202S	Oval head screw ISO 7380-1 M5x		4.00
24	A60607080000	Fuel level sensor		1.00
25	A60605090000	Heat protection rear tank		1.00
26	0025050126	HH collar screw M5x12 TX30		3.00
30	76107040000	Seat		1.00
31	76907040050	Seat cover		1.00
32	76907040045	Seat rubber		6.00
33	28503002010	Rubber support		2.00
34	76111056044	Retaining bracket battery cmpl		1.00
35	0024060156	HH collar screw M6x15 TX30	ONLY USA	2.00