



| Pos | Part Number | Description | Additional Text | Quantity |
|-----|-------------|-------------------------------|-----------------|----------|
| 1 | 69011075100 | MAIN WIRING HARNESS | | 1.00 |
| 2 | 69011077000 | WIRING HARNESS FRAME REARPART | | 1.00 |
| 3 | 69011048000 | BRACKET FOR PLUGS | | 1.00 |
| 4 | 69011060010 | HORN BRACKET RC8 CPL. | | 1.00 |
| 5 | 69011060000 | HORN CPL. | | 1.00 |
| 6 | 0021050003 | washer DIN 9021 A - 5.3 | | 1.00 |
| 7 | 0985050003 | Self locking nut DIN 985 M5 | | 1.00 |
| 8 | 0025080166S | HH collar screw M8x16 TX40 SL | | 2.00 |
| 9 | 69011049000 | PLUG BORD STEERING HEAD | | 1.00 |
| 10 | 58605083010 | SCREW TORX M5X10 05 | | 2.00 |
| 11 | 61111018000 | TEMPERATURE SENSOR 07 | | 1.00 |

| | | | | |
|----|-------------|------------------------------|-----------------|------|
| 13 | 58513001000 | SPIRAL HOSE D=9MM PER METER | 1 METER | 0.00 |
| 14 | 61111020000 | STARTER INTERLOCK | | 1.00 |
| 15 | 000700000AN | SPARE CONNECTOR AN 4-PINS | | 1.00 |
| 16 | 61111057000 | RELAY CM1A-R-12V-H80 07 | | 4.00 |
| 17 | 58411096100 | DIODE S3H-15 97 | | 1.00 |
| 18 | 75011088015 | FUSE 15A 07 | | 0.00 |
| 19 | 75011088010 | FUSE 10A 07 | | 0.00 |
| 20 | 75011087050 | RUBBER CASING FOR FUSE BOX | | 1.00 |
| 22 | 60011092000 | OIL-PRESSURE SWITCH CABLE 03 | | 1.00 |
| 23 | 60111094000 | CLIP 5/7 MM 06 | | 1.00 |
| 24 | 69011092000 | Cable tie w. socket D=6.5 | | 2.00 |
| 24 | 44011076100 | CABLE TIE 100/2,5MM BLACK | | 0.00 |
| 24 | 44011076200 | CABLE TIE 200/3,6MM BLACK | | 0.00 |
| 24 | 44011076305 | CABLE TIE 300/4,8MM BLACK | | 0.00 |
| 25 | 69011040000 | END PLUG CAN-BUS 08 | | 1.00 |
| 26 | 000700000BH | SPARE CONNECTOR BH 6-PINS | DIAGNOSTIC PORT | 1.00 |
| 27 | 69011078050 | BRACKET F. PLUG RC8 08 | | 1.00 |
| 28 | 58411098100 | CONTACT WASHER M6 VSV-K6 | | 1.00 |
| 30 | 69011080000 | WIRING HARNESS ADAPTER HFS | | 1.00 |