

13	A62607013085	Preload spacer tank connection		2.00
14	00050142706	VARIABLE ONE-EAR CLAMP 14,2 MM		4.00
15	61907113071	Inner ventilation hose, right		1.00
16	61907113070	Ventilation hose interior		1.00
17	0600000607001	Hose 6x13 L=70		2.00
18	61907013225	Fuel tank right cpl.		1.00
19	A62607013015	Fuel tank left cpl.		1.00
20	83008100015	Special screw M6x15x5.5		6.00
21	0024060256	HH COLLAR SCREW M6X25 TX30		3.00
22	69007028000	COLLAR BUSH. 6,2X10X21X14MM 08		5.00
23	69007027000	rubber grommet, tank mounting		5.00
24	61711094100	Cable strap w.plugin foot for		1.00
25	A62607013050	Fuel tank carrier		1.00
26	83008000012	special screw M6x12x3		4.00
27	0081050181	SCREW FOR PLASTIC K50X18 T20	300 TPI Erzbergrodeo	1.00
28	54603048600	RANGE CHANGE METAL NUT M5 INOX		6.00
29	54603048100	clip nut M6		2.00
30	63507040070	Seat bushing		2.00
31	014581060201	Count.snk screw M6x20 TX30		2.00
32	61907117033	Tank compensation line cpl.		1.00
33	58507003200	Fuel cock cpl.		2.00
34	55007006200	O-RING 11X1,8 NBR 70		2.00
35	0799050000	TAB WASHER DIN6799 RS5		2.00
36	0025060126	HH collar screw M6x12 TX30		4.00
37	58031005000	CLAMP YDNAC 10128 12MM	FOR 12 LITER TANK	2.00
38	61907080000	Fuel level sensor		1.00
39	61907080020	Sleeve nut, fuel level sensor		1.00
40	61907080010	Gasket, fuel level sensor		1.00
41	61907020000	Pre-formed hose for tank overf		1.00
42	69015019010	HOSE CONNECTION STRAIGHT		1.00
43	78015019000	HOSE EPA D=6/10 L=2000MM		1.00
44	A62608046033AB	Storage compartment cpl.		1.00
45	69008021260	Special screw, M5x14		4.00
46	A62608046050	Storage compartment cover		1.00
47	A62711043000	USB-C power socket, 12-V		1.00
48	0025060106	HH collar screw M6x10 TX30		1.00
49	032000151000	Fastening clamp 10 mm		1.00
50	A62612010150	Luggageholder Plate		1.00
51	0035080406	AH-COLLAR SCREW M8X40 ISA45		4.00
52	A62607058044	Fuel tank protection set LH+RH		1.00