



Pos	Part Number	Description	Additional Text	Quantity
1	7650701304433A	FUEL TANK BLACK MATT		1.00
2	76507065000	RUBBER BEAR. BOX 12X24 L=24,5		2.00
3	76507060000	BEARING BUSHING UP		2.00
4	76507061000	BEARING BUSHING DOWN		1.00
5	76507028000	TANK-RETAINING PLATE R/S 08		1.00
6	76507027000	TANK-RETAINING PLATE L/S 08		1.00
7	0025080166	HH COLLAR SCREW M8X16 TX40		6.00
8	54806108052	BLIND RIVET 3,3X9,7 GROOVED 04		4.00
9	54806008050	QUICK RELEASE-SPRING HANGER		2.00
10	76507050000	SEAT LOCK		1.00

11	0738060181	BHCS ISO 7380 M6X18		2.00
12	76507008000	TANK PLUG 08		1.00
13	40011166100	KEY BLANK LC4/DUKE/LC8		0.00
14	58605083010	SCREW TORX M5X10 05		3.00
15	76507008050	CLOSURE FLANGE		1.00
16	0770050030	O-ring 50.00X3.00 VITON		1.00
17	76506010000	SPLASHBACK 08		1.00
18	72210079000	BUCKET		2.00
19	0025060106	HH collar screw M6x10 TX30		2.00
20	76507053000	CLAMP F. CABLE SEAT LOCK		1.00
21	76507066000	RUBB.BEAR.BOX 12x24x35 L=24,5		2.00
22	76507031044	TANK BREAT. - MODIFICATION KIT		1.00
23	0912050163	AH collar screw DIN 912 M5x16		2.00
24	58207080100	GAS-LEVEL SENSOR ADV. 2006		1.00
25	78015021000	HOSE EPA D=4/8 L=2000MM		0.00
30	76507040000	SEAT 08		1.00
31	76507040050	SEAT COVER 08		1.00
32	75007046010	SEAT RUBBER 10 MM		6.00
33	76507048000	BRACKET F. SEAT		1.00
34	0023060123	COLLAR SCREW M6X12 TX		2.00
35	58407011100	SCREW FOR SEAT M6X11,5/8		1.00
40	7650805000030	SPOILER LEFT BLACK		1.00
41	7650805100030	SPOILER RIGHT BLACK		1.00
42	7650804100028	SIDE COVER L/S WHITE 09		1.00
43	7650804200028	SIDE COVER R/S WHITE 09		1.00
44	54806008051	QUICK RELEASE-NIPPLE 03		2.00
46	54603048100	clip nut M6		4.00
47	76508043150	collar bushing 6.5x16x5 mm		2.00
48	76508043050	COLLAR BUSHING		2.00
49	0025060166	HH collar screw M6x16 TX30		4.00
50	0025060126	HH collar screw M6x12 TX30		4.00
51	0025080306	HH collar screw M8x30		2.00