



Pos	Part Number	Description	Additional Text	Quantity
1	77030100144	ENGINE CASE CPL. EXC-F/XC-F 07		1.00
3	49030090000	DOWEL 9,8 X 7 X 10	FS-E	2.00
6	58030021000	OILDRAIN PLUG W.MAG. M 12X1,5		1.00
7	58038022000	CU-seal ring DIN7603-12X18X1.5		1.00
11	0025060456	HH COLLAR SCREW M6X45 TX30		1.00
12	0025060086	HH collar screw M6x8 TX30		2.00
19	58030080000	LOCATING SCREW M8 L=23	450/525 MXC, EXC	1.00
20	58030081000	CU-SEAL RING 8 X 14 X 3		1.00
21	61030019050	CIRCLIP OIL LEVEL GLASS 03		1.00
22	59030019000	OIL LEVEL GLASS G 1777 Y		1.00

24	59030024000	DOWEL 17 X 19 X 12		1.00
25	77030025100	GASKET FOR CLUTCH COVER 05		1.00
26	60030064070	OIL JET 70 M6X0,75 WS8 03		1.00
27	54630027000	DOWEL BUSHING 13,8X11X12		1.00
28	75030010000	CASE BUSH		2.00
30	59030058000	JET 100 BING(44-031/180) M4		1.00
31	77030058150	JET 44-031/150		1.00
34	0770120020	O-RING 12,00X2,00 NBR 70		1.00
35	77038017000	SCREW PLUG		1.00
36	59038015100	OIL SCREEN 11,8x44,5MM		1.00
37	0770090015	O-RING 9X1,5 NBR		2.00
43	7703000124415	CLUTCH COVER CPL.		1.00
44	77030047100	CHAIN DAMPERSHEET EXC-F 07		1.00
45	0025060356	HH collar screw M6x35 TX30		1.00
50	0025060656	HH COLLAR SCREW M6X65 TX30		2.00
51	0025060506	HH collar screw M6x50 TX30		7.00
52	0025060406	HH collar screw M6x40 TX30		1.00
53	0025060306	HH collar screw M6x30 TX30		2.00
54	58038028000	VALVE PISTON D=10MM		1.00
55	58038023300	PRESSURE SPRING L=25MM D=1MM		1.00
56	0908120153	threaded plug DIN 908 M12x1.5	DUKE	1.00
57	58038022000	CU-seal ring DIN7603-12X18X1.5		1.00
58	0025060256	HH collar screw M6x25 TX30		11.00
59	0025060956	HH COLLAR SCREW M6X95 TX30		2.00
60	77030099000	GASKET SET 05		1.00
61	7703002630015	CLUTCH COVER OUTSIDE 09		1.00
62	77030027000	MOLDED RING 05		1.00
64	0025060556	HH collar screw M6x55 TX30		6.00
65	0770191015	O-RING 19,00X3,00 NBR		1.00
66	58030120000	OIL FILLER CAP M24x3 W. O-R		1.00
68	0603061001	CU-SEAL RING DIN7603-6X10X1		1.00
69	0025060606	HH collar screw M6x60 TX30		1.00