



Pos	Part Number	Description	Additional Text	Quantity
1	56012001000	ASSY SUPPORT (WITHOUT HOLDER)		1.00
2	78029002000	SUPPORT CPL.		1.00
4	80029004000	GEAR SEGMENT CPL. 04		1.00
5	75029021000	EXTRACTOR PRIM. CPL.		1.00
6	77329034000	WRENCH F.MIXTURE CONTROL SCREW		1.00
7	59031017200	MIXT. CONTROL SCREW FACTORY		1.00
9	15112017000	BUSHING EXTRACTOR		1.00
10	15112018100	INTERN.BEAR.PULLER 18-23 MM		1.00
10	60029018000	INTERN.BEAR.PULLER 28 MM		1.00
12	75029050000	ON TENSIONER PL. CYLINDER HEAD		1.00

13	75029051000	PRESS OUT PUNCH CPL.		1.00
14	78029060000	VALVE SPRING TENSION APPLICAT.		1.00
15	59029019000	VALVE SPRING LEVER		1.00
16	78029009000	SEPARATOR PLATE CRANKSHAFT		1.00
17	78029005000	MOUNTING SLEEVE SSR CS		1.00
18	58012009000	FLYWHEEL EXTRACTOR	660 SMS	1.00
20	75029047000	PRESS. TOOL F. CRANKS. CPL.		1.00
21	78029049100	PRESS OUT PLATE CS CPL.		1.00
26	75029172000	SPARK PLUG WRENCH		1.00
27	78029033100	PULLER		1.00
28	51129003000	CLUTCH HOLDER		1.00
32	75029048000	CASING DISMOUNTING TOOL 07		1.00
33	6899785	LOCTITE 243 BLUE 5 ML		0.00
34	58429059000	LOCTITE 648 GREEN 10ML		0.00
35	58429059200	LOCTITE 5910 50ML		0.00
37	78029008000	PRESS. TOOL F. CRANKSHAFT		1.00
38	75029044020	PRESS PUNCH CAMSHAFT BEAR. SM.		1.00
39	75029044010	PRESS PUNCH CAMSH. BEAR. LARGE		1.00
40	0113080802	ENGINE BLOCKING SCREW		1.00
41	77329030100	PLUG IN FUSE PISTON PIN		1.00