






#, ⑤
+ GETRIEBELAGER
TRANSMISSION BEARINGS
(2 x 0625 006087,
1 x 0625 060032, 0625 060040,
0625 060042, 0625 062058,
0625 618050)

Pos	Part Number	Description	Additional Text	Quantity
1*	52330000344	ENGINE CASE CPL.M.TRAN.BEAR'		1.00
3	5033000220098	IGNIT.COVER 125/200 MAG. 01		1.00
5	54630027000	DOWEL BUSHING 13,8X11X12		2.00
21	58030021000	OILDRAIN PLUG W.MAG. M 12X1,5		1.00
22	58038022000	CU-seal ring DIN7603-12X18X1.5		1.00
39	50330039000	ENGINE CASE GASKET 0,5MM '98		1.00
40	50330040100	IGNITION COVER GASKET 2001		1.00
42	0015060503	HH COLLAR SCREW M 6X50 WS=8		6.00
43	0015060553	HH COLLAR SCREW M 6X55 WS=8		5.00
44	0015050163	HH COLLAR SCREW M 5X16 WS=8		4.00
45*	0015060603	HH COLLAR SCREW M 6X60 WS=8		1.00
92	50330092000	OIL GUARD GROMMET 25X31 '98		1.00

99	50330099000	GASKET SET 125-200 '98-'05		1.00
----	-------------	----------------------------	--	------

* = New part