



Pos	Part Number	Description	Additional Text	Quantity
1	6011000124430	REAR WHEEL CPL. 4,25X18"SW		1.00
2	6011001004433	REAR HUB CPL. BLACK		1.00
3	60010011000	Bearing spacing tube L=124.8mm		1.00
4	0625062052	Grooved ball bear. 6205-2RSHC3		2.00
5	0472052200	CIRCLIP DIN0472-52X2		1.00
6	0760305271	Radial shaft seal 30X52X7		1.00
7	60110013000	SPACER BUSH. REAR WHEEL R/S 06		1.00
8	60010015000	Spacer ring 03		1.00
9	6001007020030	RIM 4,25X18 BLACK		1.00
10	60010171000	SPOKE M5X213 19 DEG 03		18.00
11	60010071000	SPOKE M5X194 10 DEG 03		18.00
12	58309072100	SPOKE NIPPLE M5-TA 8X21MM		36.00

14	50310075100	TUBE 110/100C-18		1.00
15	60010073000	RIM TAPE 18" 50/2 0		1.00
20	60010051042	REAR SPROCKET 42-T 03		1.00
20	60010051045	REAR SPROCKET 45-T 03		0.00
21	60010052000	SPROCKET SCREW M10X1,25 03		6.00
22	0980101253	Hexag. nut DIN 980V M10X1.25 S		6.00
23	6011005004433	SPROCKET SUPPORT CPL. BLACK		1.00
24	60110012000	SPACER BUSH. SPROCKET SUPP. 06		1.00
25	60110016000	NILOS RING 6006AV		1.00
26	0625060060	BALL BEARING 6006 DDU2CG23S6NM		2.00
27	60110014000	SPACER BUSH. SPR. SUPP. IN. 06		1.00
28	54610459000	Rubber damping block 91		6.00
29	60110060000	BRAKE DISK REAR D=240MM 06		1.00
30	59009062016	SPECIAL SCREW M6X16 WS=8 10.9		6.00
32	60010081144	WHEEL SPINDLE REAR CPL.		1.00
33	60010084000	Chain tension adjuster, right,		1.00
34	60010086000	COLLAR NUT WH. SPINDLE REAR 03		1.00
35	58414030000	HH COLLAR NUT M10X1,25 WS=13	MINI ADV.	2.00
36	50304040100	screw M10x1.25x50 WS10		2.00
37	60010365118	CHAIN 525 INCL. MASTER LINK	RIVET TOOL NECCESARY	1.00
38	60010266000	MASTER LINK FOR CHAIN 525 07	NEEDS RIVET TOOL	0.00
42	60142021000	SENSOR WHEEL REAR 06		1.00
98	00050000915	SPOKE KIT REAR "18"		0.00
99	60010015010	REAR WHEEL REP. KIT ADV		0.00