



Pos	Part Number	Description	Additional Text	Quantity
1*	61105107100	EXHAUST PIPE FRONT		1.00
2	61105108000	EXHAUST PIPE REAR 08		1.00
3	61005005000	Exhaust gasket 05		2.00
4	61005009000	SPACER BUSH. 8,5X15X7,5 05		2.00
5	51010086100	self-locking nut M8 Cu		5.00
8	61041090000	LAMBDA SENSOR 05		2.00
10	61105007049	CLAMP EXHAUST PIPE 08		1.00
11	0025080406	HH COLLAR SCREW M8X40 TX40		1.00
12	0021080003	WASHER DIN9021-A 8,4		1.00
13	51005067000	INSULATE WASHER 8,5X28X3		1.00

14	58405050065	collar bushing 8.5x12x23.5x10	2.00
15	62505015150	EXHAUST PIPE BRACKET FRONT 07	1.00
16	0025080356	HH collar screw M8x35 TX40	2.00
17	54305068100	damp. component silicone grey	3.00
18	0125080003	washer DIN 125 A -8.4	1.00
20*	61105051000	EXHAUST CLAMP 52,2MM 07	1.00
21	58405005001	Graphite ring 45X50X25	1.00
22*	0137060003	spring washer DIN 137 B - 6	2.00
30	61005052000	EXHAUST CLAMP CPL. 05	1.00
31	61105083000	SILENCER 07	1.00
32	6110519002049	HEAT PROTECTOR L/S CARBON 07	1.00
33	6110519003049	HEAT PROTECTOR CARBON R/S 07	1.00
34	61105190022	THER.PROT.FOIL SILENCER L/S	1.00
35	61105190032	THER.PROT.FOIL SILENCER R/S	1.00
36	61005091000	DAMP. COMPON. SILICONE GREY 05	6.00
37	54603048100	clip nut M6	2.00
38	0738060101	Oval head screw ISK ISO7380 M6	2.00
39	61005083011	ANTI-ROTATION ELEMENT CPL. 05	2.00
40	0025080256	HH collar screw M8x25	2.00
41	61005013000	RUBBER SILENCER SUPPORT 05	2.00
42	61005014000	Sleeve silencer support	2.00

* = New part