



Pos	Part Number	Description	Additional Text	Quantity
1*	6111000114430	REAR WHEEL CPL. BLACK 11		1.00
2	0625062052	Grooved ball bear. 6205-2RSHC3		2.00
3	61010011000	BEARING SPACER TUBE REAR 05		1.00
4	0472052200	CIRCLIP DIN0472-52X2		1.00
5	0760305271	Radial shaft seal 30X52X7		1.00
6	60010013000	SPACER BUSH. REAR WHEEL R/S 03	FOR SWINGARM BEARING	1.00
7	69010054000	BEAR.DIST. RING 30,3X37,8X4,65		1.00
9	0912060453	AH SCREW DIN0912-M 6X45		1.00
10	0912060303	AH SCREW DIN0912-M 6X30		2.00
11	6901005004430	SPROCKET SUPPORT CPL. BLACK		1.00

12	60110014000	SPACER BUSH. SPR. SUPP. IN. 06		1.00
13	0625060060	BALL BEARING 6006 DDU2CG23S6NM		2.00
14	60110016000	NILOS RING 6006AV		1.00
15	60110012000	SPACER BUSH. SPROCKET SUPP. 06		1.00
16	61010059000	DAMPING RUBBER 05		5.00
17	61010051140	REAR SPROCKET 40-T STEEL 05		0.00
17	61010051138	REAR SPROCKET 38-T STEEL 05		1.00
17	61010051139	REAR SPROCKET 39-T STEEL 05		0.00
18	61010056000	BOLT FOR SPROCKET SUPPORT 05		5.00
19	61010057000	NUT REAR SPROCKET 05		5.00
20	61010060000	BRAKE DISK REAR D=240MM 05		1.00
21	61009062018	SPECIAL SCREW M8X18 05		5.00
22	60010081144	WHEEL SPINDLE REAR CPL.		1.00
23	60010084000	Chain tension adjuster, right,		1.00
24	61010086000	Collar nut M25X1.5 WS=32 05		1.00
25	50304040100	screw M10x1.25x50 WS10		2.00
26	58414030000	HH COLLAR NUT M10X1,25 WS=13	MINI ADV.	2.00
27	60010365118	CHAIN 525 INCL. MASTER LINK	RIVET TOOL NECCESARY	1.00
28	60010266000	MASTER LINK FOR CHAIN 525 07	NEEDS RIVET TOOL	0.00
29	00050000120	STICKER MARCH. 2L/S+2R/S WHITE		1.00
30	61310945000	CRASH PADS REAR		1.00
31	58709076000	VALVE CPL. BREMBO DUKE 2003		1.00
98	00050002021	DRIVETRAIN KIT SD/SD-R 16T/38T		0.00
99	61010015000	REAR WHEEL REP. KIT		0.00

* = New part